

Florida Injection Service

6281 39th St. N. Suite G, Pinellas Park Fl 33781 727-459-8394

Here are some handy installation tips for you:

Make sure you have fresh gas in the tank. For boats, small engines and motorcycles, non-ethanol is best.

Flush out fuel rails and fuel lines as best you can with brake clean.

Check fuel rails and manifolds for foreign objects, old o-rings or defects that will damage o-rings.

Change the fuel filter(s) prior to installing the injectors.

Use white lithium grease on o-rings.

Do not use other kinds of lubricants including gasoline, bearing grease, motor oil, etc. for seal lube.

Cycle key from off to on (on, not start) five times. This will prime the fuel system and make the engine easier to start. Start engine for a few seconds then stop. Look for leaks.

Sometimes an engine will run rough when starting. Shutting it off and letting it sit for a minute will help. Start and repeat if necessary.

If you have any questions, please call us at 727-459-8394.

Thank you for your order!

~Florida Injection